



NOTES:

1. FOR THE RETROFIT OF EXISTING DECKS, DRAIN ROCK SHOULD BE INSTALLED AS FAR BACK UNDER THE LOW ELEVATED STRUCTURE AS POSSIBLE. DISTANCE DEPENDS ON ACCESSIBILITY UNDER THE STRUCTURE.
2. USE WASHED, CLEAN 3/4" TO 1-1/2" DRAIN ROCK. NATIVE ROCK MAY BE SUBSTITUTED IF AVAILABLE.
3. FOLLOW FIRE DEFENSIBLE SPACE GUIDELINES. SEE "LIVING WITH FIRE" AT WWW.LIVINGWITHFIRE.INFO.

Rock Armor - Elevated Structure



THE TAHOE REGIONAL PLANNING AGENCY (TRPA) SHALL NOT BE RESPONSIBLE FOR THE ACCURACY OR COMPLETENESS OF ELECTRONIC COPIES OF THIS DETAIL.

BMP-211
November 2012