



NOTES:

1. THE WEIR OR ORIFICE DIVERTS FLOWS INTO THE LOW FLOW CHANNEL AND ALLOWS LARGER STORMS TO BYPASS.
2. ALWAYS INCORPORATE SUMPS AND HOODS WITHIN THE FLOW SPLITTER TO PROTECT THE OUTLET PIPES.
3. INCORPORATE SCOUR PROTECTION TO THE OUTLETS OF THE LOW FLOW AND BYPASS CHANNELS.

Flow Splitter



THE TAHOE REGIONAL PLANNING AGENCY (TRPA) SHALL NOT BE RESPONSIBLE FOR THE ACCURACY OR COMPLETENESS OF ELECTRONIC COPIES OF THIS DETAIL.

BMP-304
November 2012